



Note: This IBM PC BIOS API call is for DOS/Win16 personality only. Use [Family API](#) for portability.

Note: [osFree Macro Library](#) provides macros for most of functions

2022/03/13 05:41 · prokushev · [0 Comments](#)

Int 12H

Version

IBM 5150 and later

Brief

Get memory size

Family API

[DosMemAvail](#)

Input

none

Return

- AX = kilobytes of contiguous memory starting at absolute address 00000h

Macro

```
INCLUDE BIOS.INC
```

```
@MemSize
```

Notes

- this call returns the contents of the word at 0040h:0013h; in PC and XT, this value is set from the switches on the motherboard

Note

Text based on [Ralf Brown Interrupt List Release 61](#)

| IBM PC BIOS API | |
|-----------------------------|--|
| Video I/O | INT 10H: 00H, 01H, 02H, 03H, 05H, 06H, 07H, 08H, 09H, 0AH, 0BH, 0CH, 0DH, 0EH, 0FH |
| Hardware info | INT 11H, INT 12H |
| Serial I/O | INT 14H: 00H, 01H, 02H, 03H |
| Tape I/O | INT 15H: 00H, 01H, 02H, 03H |
| Keyboard I/O | INT 16H: 00H, 01H, 02H |
| Printer I/O | INT 17H: 00H, 01H, 02H |
| Disk I/O | INT 13H: 00H, 01H, 02H, 03H, 04H, 05H |
| Date and Time | INT 1AH: 00H, 01H |
| osFree Macro Library | |
| Video I/O | @SetMode @SetCurSz @SetCurPos @GetCur @SetPage @ScrollUp @ScrollDn @Scroll @GetChAtr @PutChAtr @PutCh @SetPalet @SetColor @SetDot @GetDot @WrtTTY @VideoState @GetMode @GetDisplay @GetVideoState @GetEGAInfo @Cls |
| Hardware info | @Equipment @MemSize |
| Serial I/O | @AuxInit @AuxSendChar @AuxRecieveChar @AuxStatus |
| Tape I/O | @TapeOn @TapeOff @TapeRead @TapeWrite |
| Keyboard I/O | @KbdStatus @CharIn @CharPeek |
| Printer I/O | @PrnPrint @PrnInit @PrnStatus |
| Disk I/O | @DskReset @DskStatus @DskRead @DskWrite @DskVerify @DskFormat |
| Date and Time | @SetTime @GetTime |
| Mouse | @MouInit @MouShowPointer @MouStatus @MouSetPos @MouSetMickey @MouRegion |
| Memory manager | @ModBlok SET_BLOCK |

2022/10/04 14:28 · [prokushev](#) · [0 Comments](#)

2022/03/13 05:54 · [prokushev](#) · [0 Comments](#)

| Family API | | |
|------------|-----------------|--|
| DOS | Process Manager | DosBeep DosExit DosSleep DosExecPgm |
| | File Manager | DosChDir DosChgFilePtr DosClose DosDelete DosDupHandle DosMkDir DosMove DosQCurDir DosQCurDisk DosSetFileMode DosOpen DosQFileInfo DosRead DosQFileMode DosQFSInfo DosQVerify DosRmdir DosSelectDisk DosFindClose DosFindFirst DosFindNext DosSetFileInfo DosSetVerify DosWrite DosFileLocks DosSetFHandState DosNewSize DosBufReset DosQFHandState DosSetFSinfo DosShutdown |
| | Memory Manager | DosFreeSeg DosSubAlloc DosSubFree DosSubSet DosAllocHuge DosAllocSeg DosReallocHuge DosReallocSeg DosGetHugeShift DosCreateCSAlias |
| | NLS | DosCaseMap DosGetCtryInfo DosGetDBCSEv DosSetCtryCode DosGetCollate DosGetMessage DosInsMessage DosPutMessage |
| | Date and Time | DosSetDateTime DosGetDateTime |
| | Devices | DosDevConfig DosDevIOct1 DosDevIOct2 |
| | Signals | DosHoldSignal DosSetSigHandler |
| | Misc | BadDynLink DosGetEnv DosGetMachineMode DosGetVersion DosError DosErrClass DosSetVec |
| KBD | | KbdCharIn KbdFlushBuffer KbdGetStatus KbdSetStatus KbdStringIn KbdPeek |
| VIO | | VioGetBuf VioGetConfig VioGetCurPos VioGetCurType VioGetPhysBuf VioReadCellStr VioReadCharStr VioScrollUp VioScrollDn VioScrollLf VioScrollRt VioScrUnLock VioSetCurPos VioSetCurType VioSetMode VioGetMode VioShowBuf VioWrtCellStr VioWrtCharStr VioWrtCharStrAtt VioWrtNAttr VioWrtNCell VioWrtNChar VioWrtTTY VioScrLock VioPopUp |
| Tools | | BIND |
| Modules | | DOSCALLS.DLL VIOCALLS.DLL KBDCALLS.DLL MSG.DLL |
| Libraries | | API.LIB OS2386.LIB FAPI.LIB DOSCALLS.LIB SUBCALLS.LIB |

2018/08/25 15:05 · prokushev · 0 Comments

From:
<https://www.osfree.ru/doku/> - **osFree wiki**

Permanent link:
<https://www.osfree.ru/doku/doku.php?id=en:docs:bios:api:int12>

Last update: **2022/03/27 08:55**

